

# Nuage I/O Firmware V1.15 Release Notes

---

## Contents

[System Component Compatibility](#)

[Main Revisions and Enhancements](#)

[Update History](#)

## System Component Compatibility

Please make sure to use the appropriate versions of NUAGE system components which are compatible with each other, referring to the following website. Using an unsupported component combination may result in malfunction.

[http://www.yamahaproaudio.com/global/en/products/daw\\_systems/nuage/downloads.jsp](http://www.yamahaproaudio.com/global/en/products/daw_systems/nuage/downloads.jsp)

### NOTE


After you update the Nuage I/O firmware by using NUAGE Workgroup Manager, be sure to manually turn on Nuage I/O again.


## Main Revisions and Enhancements

### V1.14 → V1.15

#### Improvement

- Dante [SYNC] indicator (orange) flashes when communication error occurs on the Dante Redundant Network.

- Error on a primary network:      Light or flash (green)  Flashes once (orange)

- Error on a secondary network:      Light or flash (green)  Flashes twice (orange)

#### Fixed Bugs

- Solved some other minor problems.

## Update History

### V1.13 → V1.14

#### Fixed Bugs

- Solved a problem in which synchronization with the Dante network was unlocked and the audio was muted for several seconds depending on your system.
- Solved some other minor problems.

### V1.12 → V1.13

#### Fixed Bugs

- Solved a problem in which audio was sometimes cut off when the cable of the [PRIMARY] connector was disconnected and then reconnected while Nuage I/O was being used in a redundancy network.
- Solved some other minor problems.

### V1.11 → V1.12

- Improved the data processing capacity of the Nuage I/O.

#### Fixed Bugs

- Solved a problem in which an instantaneously noise would occur when, after turning on the power of Nuage I/O, the “Active” indications in the Workgroup would come on for the first time.
- Solved some other minor problems.

### V1.09 → V1.11

#### Fixed Bugs

- Solved a problem in which Nuage I/O would no longer clock correctly if the word clock source is re-connected to the BNC or AES/EBU on the Nuage I/O, after the unit receives a stable clock. Also solved a problem in which (in the above situation) the SAMPLE RATE indicator on the front panel would not flash even though the unit was not clocking properly.
- Solved a problem in which sync loss may occur among samples between different channels within a NUAGE series device or between different NUAGE series devices.
- Solved a problem in which the Input Trim/Output Trim functions of the Nuage I/O 16A or 8A8D, which was adjusted by using NUAGE Workgroup Manager, would not be changed correctly.

---

Company and product names that appear in this document are the trademarks or registered trademarks of their respective companies.

(C) 2013-2015 Yamaha Corporation.

# Nuage I/O ファームウェア V1.15 リリースノート

---

## 目次

[NUAGE システムコンポーネントの互換性](#)

[主なアップデートの内容](#)

[更新履歴](#)

## NUAGE システムコンポーネントの互換性

NUAGE システム製品は、下記のウェブサイト参照して互換性のあるバージョンをお使いください。互換性の無いバージョンを組み合わせで使った場合、誤動作の原因になることがあります。

[http://www.yamahaproaudio.com/japan/ja/products/daw\\_systems/nuage/downloads.jsp](http://www.yamahaproaudio.com/japan/ja/products/daw_systems/nuage/downloads.jsp)

## NOTE

NUAGE Workgroup Manager を使って Nuage I/O のファームウェアをアップデートした後は、必ず手動で Nuage I/O の電源を入れ直してください。

## 主なアップデートの内容

### V1.14 → V1.15

#### 改善点

- Dante がリダンダンシーネットワークで動作している時、主回線(プライマリー)接続または副回線(セカンダリー)接続に不具合があると、Dante [SYNC]インジケータ(橙色)が点滅するように変更しました。

- 主回線(プライマリー)の不具合: 点灯または点滅  点滅

- 副回線(セカンダリー)の不具合: 点灯または点滅  2 回点滅

#### 修正された不具合

- その他の軽微な不具合を修正しました。

## 更新履歴

### V1.13 → V1.14

#### 修正された不具合

- 使用環境によって、Dante の同期が外れ、数秒間音声ミュートされることがある問題を修正しました。
- その他の軽微な不具合を修正しました。

### V1.12 → V1.13

#### 修正された不具合

- Nuage I/O をリダンダンシーネットワークで使用中に、[PRIMARY]端子のケーブルを抜いて挿し直したときに、音声途切れることがある問題を修正しました。
- その他の軽微な不具合を修正しました。

### V1.11 → V1.12

- Nuage I/O の通信処理能力を改善しました。

#### 修正された不具合

- Nuage I/O の電源をオンにしたあと、Workgroup ではじめて Active になったとき、瞬間的にノイズが発生する問題を修正しました。
- その他の軽微な不具合を修正しました。

### V1.09 → V1.11

#### 修正された不具合

- ワードクロックソースに BNC や AES/EBU を選択し、クロックが正常に動き始めた後にそのクロックを抜き、再接続すると正常にロックしない不具合を修正しました。また、このような場合に、フロントパネルの SAMPLE RATE インジケーターが点滅しない不具合を併せて修正しました。
- 本体内部のチャンネル間や NUAGE 機器間でサンプルずれが発生することがある不具合を修正しました。
- NUAGE Workgroup Manager から Nuage I/O 16A または 8A8D の Input Trim/Output Trim を調整して電源をオフにした後、再び電源をオンにした際に設定値が正しく再現されない不具合を修正しました。

---

本文に掲載されている会社名および商品名等は、各社の登録商標または商標です。

(C) 2013-2015 Yamaha Corporation.